

### 220, 230, 240, 250

#### Parts List:

- 1 - Air Processor - Boxed
- 2 - Hand Controls - Boxed with Processor
- 2 - Non-Inflated Vulcanized Rubber Air Chambers - Wrapped
- 1 - Two Piece Mattress Cover (bottom and top) - Wrapped
- 1 - Foam Mattress Support Tray (White) - Wrapped
- 1 - Foam Topper (Blue) - Wrapped with Support Tray
- 1 - Vinyl Safety Liner (Blue) - Wrapper
- 1 - Setup Instructions
- 1 - Warranty

#### Surge Protector Recommended:

**Note:** Your 20 year limited warranty does not cover damage due to a power surge, regardless of the source.

#### Shipped:

- One Large Box
- One Medium Box



Scissors Required to Complete Set-Up -  
2 people recommended for easier assembly

**IF MISSING PARTS  
CALL 800-289-2693**

## SET UP AND ASSEMBLY

### BEFORE YOU BEGIN ALLOW FOAM TO EXPAND FOR AT LEAST 1 HOUR



1

Remove Foam Mattress Support Tray and Foam Topper from box 1. Remove plastic bag and set foam aside to recover. **Foam recovery and expansion process may take up to 1 hour.**



2

Have your foundation or platform bed base ready for new bed (not included).



3

Unzip top portion of Two Piece Mattress Cover. Set top portion (with the blue bottom) to the side.



4

Place bottom portion of Two Piece Mattress Cover on top of your foundation or platform bed base. Turn the side of the bottom cover "down" over your foundation.



5

After Mattress Support Tray has expanded, position on top of the Two Piece Mattress Cover.



6

Install Vinyl Safety Liner (blue) over Mattress Support Tray. Ensure the dull side is facing up.



7

At the head of the bed, cut a hole in the Vinyl Safety Liner to align with the hole in the Foam Support Tray rail. The air hoses will pass through this hole.



8

Bring the sides of the bottom of the Two Piece Mattress Cover up and around the Foam Mattress Support Tray.

### SET UP AND ASSEMBLY (Continued)



Place the two un-inflated air chambers side by side in the Support Tray. The chambers are labeled either left or right. The air chambers should be placed so the right/left labels are at the head of the bed.



Insert air hoses through the hole you cut in the Vinyl Safety Liner and through the pre-cut holes in the Mattress Cover and Foam Tray, making sure hoses protrude approx. 2 ft. from the head of the bed.



Place air processor under hoses protruding from the head of the bed. Connect color coded hoses from the mattress to the corresponding color coded nozzles on the processor. Hoses will "click" when securely in place.



Attach one hand control to the "LH" connector and the other control to the "RH" connector on the air processor. Standing at the foot of the bed, "LH" refers to the left side of the bed and "RH" refers to the right side of the bed.



Plug Air Processor into a surge protector and proceed to inflate air bed by pressing the auto fill button\* of each controller. Once both chambers are filled, position them evenly inside the Support Tray.  
\*2504 control does not have auto fill



Place the Foam Topper (blue), zipper side down, evenly over the surface of the two individual air chambers.



Fold the top portion of the Two Piece Mattress Cover over the Foam Topper (blue).



Zip the top portion of the Two Piece Mattress Cover to the bottom of the Two Piece Mattress Cover.

## ENJOY YOUR NEW MATTRESS!

Please allow 24-48 hours for full expansion